

RETIRED MODELS

While many of our most popular and widely used models have been renamed, some other models were retired as part of our effort to streamline our stick portfolio. Though we will no longer offer these models, we can point you to a pair within the portfolio that will most closely match your previous stick's playing characteristics.

ARTIST SIGNATURE MODELS

DISCONTINUED SKU	DISCONTINUED MODEL	ALTERNATE SKU	ALTERNATIVE MODEL
MA1	Memo Acevedo "Revolution" Timbale Stick	TH516	TH516 Timbale Stick
PW515W	Joey Jordison Shira Kashi Oak Signature	TX717W	Rick Latham Hickory Signature Model
PW707W	Ed Shaughnessy 707 Shira Kashi Oak	PW747W	Neil Peart 747 Shira Kashi Oak Signature Model
PW719W	Stephen Perkins 719 Shira Kashi Oak	PW727W	Classic Attack 727 Shira Kashi Oak Oval Wood Tip
PW777W	Classic Shira Kashi Oak 777 Wood Tip	TX721W	Marco Minnemann 721 Signature Model
TX515W	Joey Jordison Hickory Signature	TX717W	Rick Latham Hickory Signature Model
TX5AXW	Chris Adler Signature Model	TX5ALW	Classic Forward 5A Long Hickory Oval Wood Tip
TX5BXN	Jason Bittner Signature Model	RBH595N	Rebound 5B Hickory Oval Nylon Tip
TX721BW	Marco Minnemann 721B Signature Model	TX721W	Marco Minnemann 721 Signature Model
TX733W	Michael Carvin 733 Signature Model	TX718W	Finesse 718 Hickory Small Round Wood Tip
TX808W	Paul Wertico 808 Signature Model	TX808LW	Ian Paice Hickory Signature Model
TX8AW	Jim Rupp 8A Signature Model	TX7AW	Classic Forward 7A Hickory Oval Wood Tip
TXSD9W	Teddy Campbell SD9 Signature Model	SD330W	Todd Sucherman Signature Model

CLASSIC HICKORY PRO-ROUND

DISCONTINUED SKU	DISCONTINUED MODEL	ALTERNATE SKU	ALTERNATIVE MODEL
TXPR5AW	Classic 5A Pro-Round Hickory	TX707W	Simon Phillips Hickory Signature Model
TXPR5BW	Classic 5B Pro-Round Hickory	RBH595AW	Rebound 5B Hickory Acorn Wood Tip
TXPR7AW	Classic 7A Pro-Round Hickory	RBH535AW	Rebound 7A Hickory Acorn Wood Tip

CLASSIC SHIRA KASHI OAK

DISCONTINUED SKU	DISCONTINUED MODEL	ALTERNATE SKU	ALTERNATIVE MODEL
PW707N	Classic 707 Shira Kashi Oak Nylon Tip	PW747W	Neil Peart 747 Shira Kashi Oak Signature Model
PW808W	Classic 808 Shira Kashi Oak Wood Tip	PW5BW	Classic Attack 5B Shira Kashi Oak Oval Wood Tip
PWRKW	Classic Shira Kashi Oak "Rock Knocker"	PW5AW	Classic Attack 5A Shira Kashi Oak Oval Wood Tip

SELECT BALANCE FORWARD

DISCONTINUED SKU	DISCONTINUED MODEL	ALTERNATE SKU	ALTERNATIVE MODEL
F5AAG	Select Balance Forward 5A ActiveGrip Acorn Tip	R5AAG	Rebound 5A ActiveGrip Hickory Acorn Wood Tip
F5AAGC	Select Balance Forward 5A ActiveGrip Clear Acorn Tip	R5AAGC	Rebound 5A ActiveGrip Clear Hickory Acorn Wood Tip
F5AFG	Select Balance Forward 5A FireGrain Acorn Tip	R5AFG	Rebound 5A FireGrain Hickory Acorn Wood Tip
F5BAG	Select Balance Forward 5B ActiveGrip Acorn Tip	R5BAG	Rebound 5B ActiveGrip Hickory Acorn Wood Tip
F5BAGC	Select Balance Forward 5B ActiveGrip Clear Acorn Tip	R5BAGC	Rebound 5B ActiveGrip Clear Hickory Acorn Wood Tip
F5BFG	Select Balance Forward 5B FireGrain Acorn Tip	R5BFG	Rebound 5B FireGrain Hickory Acorn Wood Tip
F7AAG	Select Balance Forward 7A ActiveGrip Acorn Tip	R7AAG	Rebound 7A ActiveGrip Hickory Acorn Wood Tip
F7AAGC	Select Balance Forward 7A ActiveGrip Clear	R7AAGC	Rebound 7A ActiveGrip Clear Hickory Acorn Wood Tip
FBH535TW	Select Balance Forward .535 Hickory Teardrop Tip	TX7AW	Classic Forward 7A Hickory Oval Wood Tip
FBH550TW	Select Balance Forward .550 Hickory Teardrop Tip	TX5AW	Classic Forward 5A Hickory Oval Wood Tip
FBH565AW	Select Balance Forward .565 Hickory AcornTip	RBH565AW	Rebound 5A Hickory Acorn Wood Tip
FBH565TW	Select Balance Forward .565 Hickory Teardrop Tip	RBH565AW	Rebound 5A Hickory Acorn Wood Tip
FBH595AW	Select Balance Forward .595 Hickory Acorn Tip	RBH595AW	Rebound 5B Hickory Acorn Wood Tip
FBH595TW	Select Balance Forward .595 Hickory Teardrop Tip	RBH595AW	Rebound 5B Hickory Acorn Wood Tip
FBO535AW	Select Balance Forward 7A Oak Acorn Tip	PW7AW	Classic Attack 7A Shira Kashi Oak Oval Wood Tip
FBO565AW	Select Balance Forward 5A Oak Acorn Tip	PW5AW	Classic Attack 5A Shira Kashi Oak Oval Wood Tip
FBO595AW	Select Balance Forward 5B Oak Acorn Tip	PW5BW	Classic Attack 5B Shira Kashi Oak Oval Wood Tip
RBH535TW	Select Balance Rebound .535 Hickory Teardrop Tip	RBH535AW	Rebound 7A Hickory Acorn Wood Tip
RBH550TW	Select Balance Rebound .550 Hickory Teardrop Tip	RBH565AW	Rebound 5A Hickory Acorn Wood Tip
RBH565TW	Select Balance Rebound .565 Hickory Teardrop Tip	RBH565AW	Rebound 5A Hickory Acorn Wood Tip
RBH580TW	Select Balance Rebound .580 Hickory Teardrop Tip	RBH595AW	Rebound 5B Hickory Acorn Wood Tip
RBH595TW	Select Balance Rebound .595 Hickory Teardrop Tip	RBH595AW	Rebound 5B Hickory Acorn Wood Tip
RBM580LRW	Select Balance Rebound .580 Long Maple Round Tip	RBM595LRW	Finesse 5B Long Maple Small Round Tip
RBM580RW	Select Balance Rebound .580 Maple Round Tip	RBM595RW	Finesse 5B Maple Small Round Tip
RBO535AW	Select Balance Rebound 7A Oak Acorn Tip	PW7AW	Classic Attack 7A Shira Kashi Oak Oval Wood Tip
RBO565AW	Select Balance Rebound 5A Oak Acorn Tip	PW5AW	Classic Attack 5A Shira Kashi Oak Oval Wood Tip
RBO595AW	Select Balance Rebound 5B Oak Acorn Tip	PW5BW	Classic Attack 5B Shira Kashi Oak Oval Wood Tip

CLASSIC HICKORY

DISCONTINUED SKU	DISCONTINUED MODEL	ALTERNATE SKU	ALTERNATIVE MODEL
TX2BW-AG	Classic 2B ActiveGrip Hickory Wood Tip	R2BAG	Rebound 2B ActiveGrip Hickory Acorn Wood Tip
TX2BW-AGC	Classic 2B ActiveGrip Clear Hickory Wood Tip	R2BAGC	Rebound 2B ActiveGrip Clear Hickory Acorn Wood Tip
TX2SW	Classic 2S Hickory Wood Tip	PW2SW	Tommy Aldridge Shira Kashi Oak Signature Model
TX419W	Classic 419 Hickory Wood Tip	RBH625LAW	Rebound 2B Long Hickory Acorn Wood Tip
TX5ABN	Classic 5AB Hickory Nylon Tip	RBH565N	Rebound 5A Hickory Oval Nylon Tip
TX5ABW	Classic 5AB Hickory Wood Tip	RBH565AW	Rebound 5A Hickory Acorn Wood Tip
TX5AW-AG	Classic 5A ActiveGrip Hickory Wood Tip	R5AAG	Rebound 5A ActiveGrip Hickory Acorn Wood Tip
TX5AW-AGC	Classic 5A ActiveGrip Clear Hickory Wood Tip	R5AAGC	Rebound 5A ActiveGrip Clear Hickory Acorn Wood Tip
TX5BW-AG	Classic 5B ActiveGrip Hickory Wood Tip	R5BAG	Rebound 5B ActiveGrip Hickory Acorn Wood Tip
TX5BW-AGC	Classic 5B ActiveGrip Clear Hickory Wood Tip	R5BAGC	Rebound 5B ActiveGrip Clear Hickory Acorn Wood Tip
TX707N	Classic 707 Hickory Nylon Tip	TX5AN	Classic Forward 5A Hickory Nylon Oval Tip
TX720W	Classic 720 "Intruder" Wood Tip	RBH565LAW	Rebound 5A Long Hickory Acorn Wood Tip
TX737W	Classic 737 Hickory Wood Tip	TX718W	Finesse 718 Hickory Small Round Wood Tip
TX7AW-AG	Classic 7A ActiveGrip Hickory Wood Tip	R7AAG	Rebound 7A ActiveGrip Hickory Acorn Wood Tip
TX7AW-AGC	Classic 7A ActiveGrip Clear Hickory Wood Tip	R7AAGC	Rebound 7A ActiveGrip Clear Hickory Acorn Wood Tip
TXJZN	Classic Jazz Hickory Nylon Tip	RBH535N	Rebound 7A Hickory Oval Nylon Tip
TXRKW	Classic "Rock Knocker" Hickory	TX5AW	Classic Forward 5A Oval Wood Tip
TXSD1FW	Classic Future Pro Snare Stick Hickory	TXSD1W	Concert SD1 Hickory

OTHER

DISCONTINUED SKU	DISCONTINUED MODEL	ALTERNATE SKU	ALTERNATIVE MODEL
SD6	Maple SD6 Multi Percussion Stick	MT3	MT3 Shira Kashi Oak Multi-Purpose Mallet

STILL NEED HELP FINDING YOUR STICK?

contact us at ProMark@daddario.com